

Rocker with control window and imprint "Heizung Ein/Aus"

| Specification | Order No. | Packing unit | PS | EAN |
|--------------------|-----------|--------------|----|---------------|
| cream white glossy | 3678 01 | 1 | 01 | 4010337042327 |
| pure white glossy | 3678 03 | 10 | 01 | 4010337042358 |
| pure white matt | 3678 27 | 1 | 01 | 4010337042389 |
| anthracite | 3678 28 | 1 | 11 | 4010337042396 |
| colour aluminium | 3678 26 | 1 | 11 | 4010337042372 |
| black matt | 3678 005 | 1 | 11 | 4010337067061 |

Features

- Floating switch rocker allows automatic and precise positioning of the rocker in the cover frame.
- Quick mounting (3.5 turns per mounting claw).
- Easier claw mounting thanks to robust PZ1/slotted/PH screw head drive.
- Voltage check possible from the front.
- Uniform stripping length (11 mm) for switches and socket outlets guarantees quicker and more efficient mounting.
- Rigid and flexible conductors can be used.
- Easily accessible release lever.
- Shatter-proof thermoplastic base.

- LED lighting elements can be inserted from the front as standard.
 - By turning the lighting element 180°, you can switch between control lighting and continuous lighting depending on the switch.
-