

**Rocker, 2-gang with arrow symbols and control window
Gira F100**

Specification	Order No.	Packing unit	PS	EAN
pure white glossy	5386 112	1/5	02	4010337111757

Features

- Rocker switches to replace the original rockers with printed symbols.
- Universally usable for either left or right rocker.

Notes

- Using a metal top unit and/or metal cover frames can lead to impairments to the range.